

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2012 by Big Bike Parts, Inc.
No part of this instruction sheet may be
reproduced without the written permission
of Big Bike Parts, Inc.©

PART NO. WINDSHIELD GARNISH
52-795 FOR HONDA GL1800
GOLDWING 2001-2010 & 2012

4/16/2012

ITEMS REQUIRED: 10MM WRENCH

INSTALLATION:

1. RELEASE THE HEIGHT ADJUSTMENT LEVER (1A) (LEFT & RIGHT).
2. PULL BACK THE RUBBER COVER (1B) OVER LEFT & RIGHT MIRRORS.
3. USING 10MM WRENCH REMOVE THE BOLT (2A), WASHER (2B) AND RUBBER WASHER (2C) ON BOTH SIDES. BE CAREFUL NOT TO DROP ANY OF THE HARDWARE.

NOTE: THE MIRROR CAN BE TILTED FORWARD TO HELP GAIN ACCESS TO BOLT.

4. PULL THE OLD WINDSHIELD GARNISH STRAIGHT (2D) OUT TO RELEASE THE BOSSES (2E) FROM THE GROMMETS (2F).
5. INSTALL THE NEW WINDSHIELD GARNISH IN THE REVERSE OF REMOVAL.

