





INSTALLATION INSTRUCTIONS

LK-C-MAV-15

Item	Description	Qty
A	Front Brackets	2 Pr
B	Rear Brackets	2 Pr
C	M6-1.0 x 55mm Lg. HHCS	2
D	M6-1.0 Nylock Nuts	2
E	M10-1.50 Nylock Nuts	2
F	M6 Heavy Washers	4
G	M10-1.50 x 60mm Lg. HHCS	2
H	M10 Flat Washers	2
J	21mm Lg. Spacers (Front)	4
K	31.5mm Lg. Spacers (Rear)	2
L	M12-1.75 x Nylock Nuts	4
M	M12-1.75 x 65mm Lg. HHCS	4



Read instructions and view illustrations before beginning.


Liability Statement

This product is designed for use on ATVs and/or RUVs to increase ground clearance and fender clearance. It is designed for utility type, slow-speed use on relatively flat terrain in deep mud or snow. Purchasers should be aware that use of this product may increase the frequency of required maintenance, part wear, and will raise the center of gravity on your ATV and/or RUV, increasing risk of roll-over, injury and death on all types of terrain. It is your responsibility to always inform other operators and passengers of this vehicle about the added risks.

We recommend that wider tires and/or wheel spacers be used to achieve a wider stance and to improve stability of the ATV and/or RUV. Riders should be advised that the handling characteristics of a taller ATV and/or RUV are different and require extra care when riding, particularly on side hills or off-camber situations. If you further raise the center of gravity by adding taller tires, heavy loads to racks or seats, or by any other means, the ATV and/or RUV must be operated with even more care, at slower speeds and on relatively flat ground. All turns should be done at a slow speed, even on level ground.

If this product is not what you expected, or is not consistent with your intended use, you should return the product immediately to the seller, before installation, for a refund of the purchase price; less any fees. After installation, product is warranted for 90 days for defects in workmanship and materials. Warranty is limited to refund of the purchase price or replacement of the kit, at the seller's option.

kit contents continued



M10-1.50 Nylock Nut (E)




21mm Lg. Spacer (J)




M6-1.0 Nylock Nut (D)




31.5mm Lg. Spacer (K)




M6 Heavy Washer (F)




M10 Flat Washer (H)




M10-1.50 x 60mm Lg. HHCS (G)



M12-1.75 Nylock Nut (L)



M6-1.0 x 55mm Lg. HHCS (C)






M12-1.75 x 65mm Lg. HHCS (M)



Do not tighten hardware completely unless noted.

1. Raise Front of machine off ground, secure with jack stands, and remove Wheels.
2. Remove Shocks from Frame. See Fig. 1.
3. Install Front Brackets (A) to Frame. See Fig. 2.
 - Secure with M6-1.0 x 55mm Lg. HHCS (C), M6-1.0 Nylock Nut (D), (2) M6 Heavy Washers (F), and 21mm Lg. Spacer (J). See Fig. 2.
 - Complete with M10-1.50 x 65mm Lg. HHCS (G), 21mm Lg. Spacer (J), and M10-1.50 Nylock Nut (E). See Fig. 2. *2014 Models will use M12-1.75 x 65mm Lg. HHCS (M) and M12-1.75 Nylock Nut (L).*
4. See Lift Settings and reinstall Shock with stock hardware. See Fig. 3.
5. Repeat steps for opposite side.

Front (Passenger Side shown)






REAR (Passenger Side shown)

Do not tighten hardware completely unless noted.

Keep stock hardware for reuse.

1. Raise Rear of machine off ground, secure with jack stands, and remove Wheels.
2. Remove Shocks from Frame. See Figs. 4 - 4a.
3. Install Rear Brackets (B) to Frame. See Fig. 5.
 - Secure with M10-1.50 x 65mm Lg. HHCS (G), 31.5mm Lg. Spacer (K), M10 Flat Washer (H), and M10-1.50 Nylock Nuts (E). See Fig. 5.
 - 2014 Models will use M12-1.75 x 65mm Lg. HHCS (M) and M12-1.75 Nylock Nuts (L).
4. Reinstall Shock with stock hardware. See Fig. 6.
5. Repeat steps for opposite side.



- !** 2014 Models use:
- M12-1.75 x 65mm Lg. HHCS (M)
 - M12-1.75 Nylock Nut (L)